

[< Select a difference device](#)

ThinkCentre M70s Gen 6
(12YJ,12YK,12YN,12YQ,
13BQ,13BR)

Graphics Mode

Simulators: 1640, BSC V4.1.0
Lenovo ISS-KME Team
Contributed by Zongquan, v2.0, 202
5/05/20

[Notice](#)

EXPORT



Setup Menu

- Main
- Devices
- Advanced
- Power
- Security**
- Startup
- Exit



Security

Supervisor Password Not Installed

NULL String

Power-On Password Not Installed

NULL String

System Management Password Not Installed

NULL String

Set Supervisor Password Enter

Select this line to set, change, or delete the Supervisor Password.
NOTE:
To delete Supervisor Password, enter blank fields for each new password line item.

Set Power-On Password Enter

Select this line to set, change, or delete the Power-On Password.
NOTE:
To delete Power-On Password, enter blank fields for each new password line item.

Set System Management Password Enter

Select this line to set, change, or delete the System Management Password (SMP) .
NOTE:
To delete System Management Password, enter blank fields for each new password line item.

- > **System Management Password Access Control**
System Management Password prevents unauthorized user from accessing BIOS Setup in default.

- > **Hard Disk Password**
Configure hard disk password.

- > **Password Policies**
Configure the password policies

Secure Roll Back Prevention Yes ▾

[Yes] - Flash BIOS to a previous or current version is not

F1 Help

Esc Exit

↑↓

↔

Select Item

Select Menu

+/-

Enter

Change Values

Select > Sub-Menu

F9

F10

Setup Defaults

Save and Exit